

ADJ EVENT BAR PRO - DMX TRAITS - 2 CHANNEL MODE

CHANNEL	DMX VALUES	FUNCTION
1		<i>Shows</i>
	000 - 007	Blackout
	008 - 037	Show 1
	038 - 067	Show 2
	068 - 097	Show 3
	098 - 127	Show 4
	128 - 157	Show 5
	158 - 187	Show 6
	188 - 217	Show 7
	218 - 247	Show 8
	248 - 254	Random Show
	255	Sound Active
2		<i>Show Speed/Sound Sensitivity</i>
	000 - 255	Show Speed, slow to fast Sound Sensitivity, least sensitive to most sensitive

Note:

- When Channel 1 is set to a value between 008 - 254, Channel 2 will control the show speed.
- When Channel 1 is set to a value of 255, Channel 2 will control the sound sensitivity.

ADJ EVENT BAR PRO - DMX TRAITS - 17 CHANNEL MODE

CHANNEL	DMX VALUES	FUNCTION
1	000 - 255	<i>Pan (Head 1)</i>
2	000 - 255	<i>Pan Fine (Head 1)</i>
3	000 - 255	<i>Tilt (Head 1)</i>
4	000 - 255	<i>Tilt Fine (Head 1)</i>
5	000 - 255	<i>Pan (Head 2)</i>
6	000 - 255	<i>Pan Fine (Head 2)</i>
7	000 - 255	<i>Tilt (Head 2)</i>
8	000 - 255	<i>Tilt Fine (Head 2)</i>
9	000 - 255	<i>Pan (Head 3)</i>
10	000 - 255	<i>Pan Fine (Head 3)</i>
11	000 - 255	<i>Tilt (Head 3)</i>
12	000 - 255	<i>Tilt Fine (Head 3)</i>
13	000 - 255	<i>Pan (Head 4)</i>
14	000 - 255	<i>Pan Fine (Head 4)</i>
15	000 - 255	<i>Tilt (Head 4)</i>
16	000 - 255	<i>Tilt Fine (Head 4)</i>
17	000 - 255	<i>Master Dimmer, 0% - 100%</i>

ADJ EVENT BAR PRO - DMX TRAITS - 20 CHANNEL MODE

CHANNEL	DMX VALUES	FUNCTION
1	000 - 255	<i>Pan (Head 1)</i>
2	000 - 255	<i>Pan Fine (Head 1)</i>
3	000 - 255	<i>Tilt (Head 1)</i>
4	000 - 255	<i>Tilt Fine (Head 1)</i>
5	000 - 255	<i>Head 1 Dimmer, 0% - 100%</i>
6	000 - 255	<i>Pan (Head 2)</i>
7	000 - 255	<i>Pan Fine (Head 2)</i>
8	000 - 255	<i>Tilt (Head 2)</i>
9	000 - 255	<i>Tilt Fine (Head 2)</i>
10	000 - 255	<i>Head 2 Dimmer, 0% - 100%</i>
11	000 - 255	<i>Pan (Head 3)</i>
12	000 - 255	<i>Pan Fine (Head 3)</i>
13	000 - 255	<i>Tilt (Head 3)</i>
14	000 - 255	<i>Tilt Fine (Head 3)</i>
15	000 - 255	<i>Head 3 Dimmer, 0% - 100%</i>
16	000 - 255	<i>Pan (Head 4)</i>
17	000 - 255	<i>Pan Fine (Head 4)</i>
18	000 - 255	<i>Tilt (Head 4)</i>
19	000 - 255	<i>Tilt Fine (Head 4)</i>
20	000 - 255	<i>Head 4 Dimmer, 0% - 100%</i>

ADJ EVENT BAR PRO - DMX TRAITS - 22 CHANNEL MODE

CHANNEL	DMX VALUES	FUNCTION
1	000 - 255	<i>Pan (Head 1)</i>
2	000 - 255	<i>Pan Fine (Head 1)</i>
3	000 - 255	<i>Tilt (Head 1)</i>
4	000 - 255	<i>Tilt Fine (Head 1)</i>
5	000 - 255	<i>Head 1 Dimmer, 0% - 100%</i>
6	000 - 255	<i>Pan (Head 2)</i>
7	000 - 255	<i>Pan Fine (Head 2)</i>
8	000 - 255	<i>Tilt (Head 2)</i>
9	000 - 255	<i>Tilt Fine (Head 2)</i>
10	000 - 255	<i>Head 2 Dimmer, 0% - 100%</i>
11	000 - 255	<i>Pan (Head 3)</i>
12	000 - 255	<i>Pan Fine (Head 3)</i>
13	000 - 255	<i>Tilt (Head 3)</i>
14	000 - 255	<i>Tilt Fine (Head 3)</i>
15	000 - 255	<i>Head 3 Dimmer, 0% - 100%</i>
16	000 - 255	<i>Pan (Head 4)</i>
17	000 - 255	<i>Pan Fine (Head 4)</i>
18	000 - 255	<i>Tilt (Head 4)</i>
19	000 - 255	<i>Tilt Fine (Head 4)</i>
20	000 - 255	<i>Head 4 Dimmer, 0% - 100%</i>
21	000 - 255	<i>Master Dimmer, 0% - 100%</i>
22		Strobe
	000	Open
	001 - 005	Reset
	006 - 255	Strobing, slow to fast

ADJ EVENT BAR PRO - DMX TRAITS - 25 CHANNEL MODE

CHANNEL	DMX VALUES	FUNCTION
1	000 - 255	<i>Pan (Head 1)</i>
2	000 - 255	<i>Pan Fine (Head 1)</i>
3	000 - 255	<i>Tilt (Head 1)</i>
4	000 - 255	<i>Tilt Fine (Head 1)</i>
5	000 - 255	<i>Head 1 Dimmer, 0% - 100%</i>
6	000 - 255	<i>Pan (Head 2)</i>
7	000 - 255	<i>Pan Fine (Head 2)</i>
8	000 - 255	<i>Tilt (Head 2)</i>
9	000 - 255	<i>Tilt Fine (Head 2)</i>
10	000 - 255	<i>Head 2 Dimmer, 0% - 100%</i>
11	000 - 255	<i>Pan (Head 3)</i>
12	000 - 255	<i>Pan Fine (Head 3)</i>
13	000 - 255	<i>Tilt (Head 3)</i>
14	000 - 255	<i>Tilt Fine (Head 3)</i>
15	000 - 255	<i>Head 3 Dimmer, 0% - 100%</i>
16	000 - 255	<i>Pan (Head 4)</i>
17	000 - 255	<i>Pan Fine (Head 4)</i>
18	000 - 255	<i>Tilt (Head 4)</i>
19	000 - 255	<i>Tilt Fine (Head 4)</i>
20	000 - 255	<i>Head 4 Dimmer, 0% - 100%</i>
21	000 - 255	<i>Master Dimmer, 0% - 100%</i>
22		Strobe
	000	Open
	001 - 005	Reset
	006 - 255	Strobing, slow to fast

CONTINUED ON NEXT PAGE

ADJ EVENT BAR PRO - DMX TRAITS - 25 CHANNEL MODE

CHANNEL	DMX VALUES	FUNCTION
23		<i>Shows</i>
	000 - 007	Blackout
	008 - 037	Show 1
	038 - 067	Show 2
	068 - 097	Show 3
	098 - 127	Show 4
	128 - 157	Show 5
	158 - 187	Show 6
	188 - 217	Show 7
	218 - 247	Show 8
	248 - 254	Random Show
	255	Sound Active
24		<i>Show Speed/Sound Sensitivity</i>
	000 - 255	Show Speed, slow to fast Sound Sensitivity, least sensitive to most sensitive
25		<i>Dimmer Curves</i>
	000 - 020	Standard
	021 - 040	Stage
	041 - 060	TV
	061 - 080	Architectural
	081 - 100	Theatre
	101 - 255	Default to unit curve setting

Note:

- When Channel 1 is set to a value between 008 - 254, Channel 2 will control the show speed.
- When Channel 1 is set to a value of 255, Channel 2 will control the sound sensitivity.