American DJ

User Instructions



Aquarius™

Specifications:

Model: Aquarius™ Voltage: 110~220v

Lamp: JCR/H5 15v 150w

Dimensions: 5" h x 6 5/8" w x 11 3/8" L

Weight: 13.5 Lbs

Fuse: 7A

Colors: Multiple Fiber Optic

Duty Cycle: 10min 0n/0ff

HALOGEN LAMP WARNING!

This fixture is fitted with halogen lamps which are highly susceptible to damage if improperly handled. Never touch lamp with bare fingers as the oil from your hands will shorten lamp life. Also, never move fixture until lamp has had ample time to cool. Remember, lamps are not covered under warranty conditions.

The American DJ Aquarius™ comes with a 90 day limited warranty. We recommend filing out the warranty registration card included with your product to validate your warranty.

For all service please contact your nearest American DJ® dealer or see us on the web: www.americandj.com

Operating Instructions:

This unit has been lamped and tested for quality at American DJ®. This unit is ready to be plugged in and hung or set on a flat surface. The aquarius™ is a unique effect similar to the popular oil lamps such as the American DJ Groove Wheel™, the difference is that the Aquarius™ uses fiber optics to project sharp adjustable beams of light.

This unit features a fully focusable lens that is manually adjusted by turning the lens in a clockwise and counter-clockwise direction. Use the "Effect" and "Color" knobs on the rear of the unit to control the speed and rotation of the color wheel and the effect output. The color wheel can be adjusted from a static fade or a variable rotation. Use the "Effect" and "Color" knobs in conjunction with each other to create different effects. For best effect, periodically clean the front focus lens with a glass cleaner.

Lamp Replacement:

ALways disconnect the main power before attempting lamp replacement. Do not attempt to replace the lamp while the fixture is hot. Open the top cover by unscrewing the thumb screw. Carefully pull the lamp out and remove the lamp socket. Be sure to disconnect the lamp by pulling on the socket housing and not the wires. Replace the lamp and cover.

Cautions! Remember to always replace with the exact same type lamp and fuse, unless otherwise instructed by an authorized American DJ® technician.

Caution! Never open this or any other electrical unit while in use. Be sure not to obstruct the cooling vents and keep this fixture in a well ventilated area.