



CRANK 2 SYSTEM™

Portable Trussing System

CRANK 2 SYSTEM™ PARTS LIST:

2 x 5' Truss I-Beam
Part#: Z-CRANK2/IB



4 x Truss/T-Connector Locking Clip

Part#: Z-IBeam/C




4 x I-Beam Knobs w/ Wing Nuts

Part#: Z-CRANK2-IB/K
& Z-CRANK2/WN



1 x Center "I" Support bar
Part#: Z-CRANK2/IC-NH



6 x Side Mount T-Connectors

Part#: LTS/T



2 x I-Beam Connectors

Part#: Z-CRANK2/IC




4 x Safety Pins
Part#: Z-LTS/SP




2 x 10' Tri-Pod Stands
Part#: Z-CRANK2/TRIPOD







Center "I" Support Bar with T-Connectors Assembled



After T-Connector, Locking Clip, and Truss are connected. This is what it should look like.




Middle of Crank 2 System


I-Beam Connector

Center "I" Support Bar

5' Truss I-Beam



American Dq[®] CRANK 2 SYSTEM ASSEMBLY INSTRUCTIONS



ATTENTION: INSTALL GRADATION: ① — ②