

American DJ® H2O 250



User Instructions

American DJ®
4295 Charter Street
Los Angeles Ca. 90058
www.americandj.com

H2O 250™

Introduction

Introduction:

Thank you for purchasing the H2O 250™ by American DJ®. The H2O 250™ is an improvement of the very popular H2O II™. This new unit has better optics and brighter light output producing more vibrant colors. With superior optics for an overall crisp light output which intensifies the beams intensity.

Customer Support:

American DJ® provides a toll free customer support line, to provide set up help and to answer any question should you encounter problems during your set up or initial operation. You may also visit us on the web at www.americandj.com for any comments or suggestions. Service Hours are Monday through Friday 9:00 a.m. to 5:00 p.m. Pacific Standard Time.

Voice: (800) 322-6337

Fax: (323) 582-2610

E-mail: support@americandj.com

To purchase parts online visit <http://parts.americandj.com>

Warning! To prevent or reduce the risk of electrical shock or fire, do not expose this unit to rain or moisture.

Caution! There are no user serviceable parts inside this unit. Do not attempt any repairs yourself, doing so will void your manufactures warranty. In the unlikely event your unit may require service please contact American DJ.

Please recycle the shipping carton when ever possible.

H2O 250™

Unpacking

Unpacking: Every H2O 250™ has been thoroughly tested and has been shipped in perfect operating condition. Carefully check the shipping carton for damage that may have occurred during shipping. If the carton appears to be damaged, carefully inspect your units for any damage and be sure all accessories necessary to operate the system have arrived intact. In the event damage has been found or parts are missing, please contact our toll free customer support number for further instructions. Please do not return the system to your dealer without first contacting customer support.

H2O 250™

General Instructions

To optimize the performance of this product, please read these operating instructions carefully to familiarize yourself with the basic operations of this unit. These instructions contain important safety information regarding the use and maintenance of this unit. Please keep this manual with the unit, for future reference.

H2O 250™

Features

- Includes Built-In Hanging Yoke
 - 9 Colors Plus White
 - Easy Access Lamp Replacement
 - Mixed Coloring
 - Color Scroll or Color Lock Option
- LL- ELC 24v/250w Lamp


H2O 250™

Warranty Registration

The H2O 250™ carries a one year (365 days) limited warranty. Please fill out the enclosed warranty card to validate your purchase. All returned service items whether under warranty or not, must be freight pre-paid and accompany a return authorization (R.A.) number. The R.A. number must be clearly written on the outside of the return package. A brief description of the problem as well as the R.A. number must also be written down on a piece of paper and included in the shipping container. If the unit is under warranty, you must provide a copy of your proof of purchase invoice. You may obtain a R.A. number by contacting customer support at (800) 322-6337.

H2O 250™

Halogen Lamp Precautions



Halogen Lamp Warning: This fixture is fitted with halogen lamps which are highly susceptible to damage if improperly handled. Never touch the lamps with your bare fingers as the oil from your hands will shorten lamp life. Also, never move the fixture until the lamps have had ample time to cool. Remember, lamps are not covered under warranty conditions.

H2O 250™

Operating Instructions

Operation: This fixture is designed to operate as a stand alone unit and does not require a controller of any type. The H2O 250™ was created to meet the demands of theatrical groups and production groups. The desire was to create a low cost unit with an incredible effect, without any strong flashing lights or special fog needs. This unit comes with nine built-in colors that can be used to create a variety of unique effects. This fixture is ready to be plugged in right out of the box. When the unit is plugged into a matching power supply, the lamp will strike and the unit's two internal effect wheels will immediately begin to turn. On the rear of the unit there is one toggle switch that is used to control the internal color wheel. When toggle switch is in the "up" position the color wheel will automatically and continuously scroll through the color wheel. When the color wheel toggle switch is in the "down" position the color wheel will lock in place.

Color Lock: To lock the color wheel to a desire color or color combination, wait for the wheel to turn to your desired color setting and push the color wheel toggle switch to the "down" position, this will lock the color wheel into place. You can also create a more dramatic effect by using split color combinations by stopping the wheel anywhere between two adjacent colors.

H2O 250™

Trouble Shooting

Trouble Shooting: Listed below are a few common problems that you may encounter, with solutions.

No light output from the unit;

1. Be sure you have connected your unit into a wall outlet with a matching power supply.
2. Be sure the external breaker has not blown. The breaker is located on the rear panel.
3. Remove the lamp cover and be sure the lamp is seated in the socket properly. Occasionally lamps become loose during shipping, be sure the lamp is push in to the socket completely.

Unit does not color change;

1. Be sure the unit's mode switch is in the "I" position.

Caution: Always replace with the exact same type lamp, unless otherwise specified by an authorized American DJ® technician. Replace with anything other than the specified part can damage your unit and will void your manufactures warranty.

Warning: If after replacing the lamp you continue to blow lamps, STOP using the unit. Contact customer support for further instructions, you may have to return the unit for servicing. Continuing to use the unit may cause serious damage.

Lamp Replacement: Caution! Never attempt to change the lamp while the fixture is plugged in. Always disconnect the main power and allow the unit ample time to cool before attempting to replace the lamp. Lamp replacement has been made simple by incorporating the use of a flip-up front cover that is retained by thumb screws.

1. Be sure to follow the proper handling procedures that deal with halogen lamps.
2. Locate the lamp socket access door located on the top of the unit and unscrew the single thumb screw that hold the door in place.
3. After removing the thumb screw, lift the cover slightly and pull it forward to remove the door and expose the lamp socket assembly.
4. Gently remove the socket assembly from the rear of the lamp and carefully remove the old lamp and discard it in the trash.
5. Replace the lamp with an exact match and reassemble in reverse order.

Breaker Reset:

This unit is equipped with a built-in safety breaker. This breaker is designed to close the power circuit in the event of an internal short or power surge. This will reduce the risk of electrical shock or fire and protect the circuitry. To reset the breaker, push the breaker button in until you hear it “pop” back in to place. If the breaker continues to pop, stop using the unit and contact our customer support team, the unit may need to be returned for service.

1-YEAR LIMITED WARRANTY

A. American DJ® hereby warrants, to the original purchaser, American DJ® products to be free of manufacturing defects in material and workmanship for a period of one year (365 days) from the date of purchase. This warranty shall be valid only if the product is purchased within the United States of America, including possessions and territories. It is the owner's responsibility to establish the date and place of purchase by acceptable evidence, at the time service is sought.

B. For warranty service, send the product only to the American DJ® factory. All shipping charges must be pre-paid. If the requested repairs or service (including parts replacement) are within the terms of this warranty, American DJ® will pay return shipping charges only to a designated point within the United States. If the entire instrument is sent, it must be shipped in its original package. No accessories should be shipped with the product. If any accessories are shipped with the product, American DJ® shall have no liability whatsoever for loss of or damage to any such accessories, nor for the safe return thereof.

C. This warranty is void if the serial number has been altered or removed; if the product is modified in any manner which American DJ® concludes, after inspection, affects the reliability of the product; if the product has been repaired or serviced by anyone other than the American DJ® factory unless prior written authorization was issued to purchaser by American DJ®; if the product is damaged because not properly maintained as set forth in the instruction manual.

D. This is not a service contract, and this warranty does not include maintenance, cleaning or periodic check-up. During the period specified above, American DJ® will replace defective parts at its expense, and will absorb all expenses for warranty service and repair labor by reason of defects in material or workmanship. The sole responsibility of American DJ® under this warranty shall be limited to the repair of the product, or replacement thereof, including parts, at the sole discretion of American DJ®. All products covered by this warranty were manufactured after January 1, 1990, and bear identifying marks to that effect.

E. American DJ® reserves the right to make changes in design and/or improvements upon its products without any obligation to include these changes in any products theretofore manufactured.

F. No warranty, whether expressed or implied, is given or made with respect to any accessory supplied with products described above. Except to the extent prohibited by applicable law, all implied warranties made by American DJ® in connection with this product, including warranties of merchantability or fitness, are limited in duration to the warranty period set forth above. And no warranties, whether expressed or implied, including warranties of merchantability or fitness, shall apply to this product after said period has expired. The consumer's and or Dealer's sole remedy shall be such repair or replacement as is expressly provided above; and under no circumstances shall American DJ® be liable for any loss or damage, direct or consequential, arising out of the use of, or inability to use, this product.

G. This warranty is the only written warranty applicable to American DJ® Products and supersedes all prior warranties and written descriptions of warranty terms and conditions heretofore published.

H. Lamps are not covered under this or any other warranty, either written or implied.

MODEL:	H2O 250™
VOLTAGE*:	120v~60Hz or 220v~50/60Hz
LAMP:	LL-ELC 24v/250w
DIMENSIONS:	12.5" (L) x 10.9" (W) x 9.5" (H)
WEIGHT:	11 Lbs/ 5 Kgs
BREAKER:	5 Amp
WORKING POSITION:	Any Safe Position
COOLING:	Fan Cooled
GOBOS:	None
COLORS:	9 <i>plus</i> White
WARRANTY:	1 YEAR (365 DAYS)

* Voltage is preset at the factory

Please Note: Specifications and improvements in the design of this unit and this manual are subject to change without any prior written notice.

©American DJ®
World Headquarters:
4295 Charter Street Los Angeles, CA 90058 USA
Tel: 323-582-2650 Fax: 323-582-2610
Web: www.americandj.com E-mail: info@americandj.com