

DMX TRAITS

CHANNEL			DMX VALUE	FUNCTION
1CH	3CH	4CH		
	1	1		Strobe
			0-31	LED off
			32-63	LED on
			64-95	Strobe Slow > Fast
			96-127	LED on
			128-159	Strobe Pulse Slow > Fast
			160-191	LED on
			192-223	Random Strobe Slow > Fast
			224-255	LED on
1	2	2	0-255	Dimmer
		3	0-255	Dimmer Fine
	3	4		Dim Curves
			0-20	Standard
			21-40	Stage
			41-60	TV
			61-80	Architectural
			81-100	Theatre
			101-120	Stage 2
			121-255	Default to Unit Setting