

American DJ® User Instructions

X-Ray II™

Thank you for purchasing this American DJ® product. For your convenience this lighting effect has been lamped and is ready to be used, there is no assembly required. Please read the following instructions before installing or using your new unit.

Operating Instructions:

Unit is ready to be hung or set on the ground. Lights will react to the music via its own internal microphone. The X-Ray™ produces an unique flat, rotating multi-colored X-beams of light from its special fan shaped lamp.

To replace lamp; unscrew 3 screws around side of the ball, replace bulbs, and reassemble.

For service, contact your *American DJ®* dealer.

Caution! Always disconnect from main power before replacing lamps or servicing unit. Remember to always replace with same lamps and fuses.

HALOGEN LAMP WARNING!

This fixture is fitted with halogen lamps which are highly susceptible to damage if improperly handled. Never touch lamp with bare fingers as the oil from your hands will shorten lamp life. Also, never move fixture until lamp has had ample time to cool. Remember, lamps are not covered under warranty conditions.



Model: X-Ray II™

SPECIFICATIONS:

Lamp: 2x ZB-EHM
300W 120V

Power: 110V 60Hz

Working Position: Any

Weight: 9 lbs.

Size: 14" x 12" x 12"

Duty Cycle: 10 min. on
10 min. off

Fuse: GMA 7A