



DMX OPERATOR 384

SOFTWARE UPDATE INSTRUCTIONS

1. Power OFF the DMX Operator-384.
2. Connect a USB cable between a PC computer and the DMX Operator 384.
3. On the DMX Operator 384, press and hold the **“PROGRAM”** button down and power ON the DMX Operator 384. Within a few seconds, DMX Operator 384 will display **“USB”**.
4. On your PC, the DMX Operator 384 will be discovered as a USB device. Locate the **“ADJ_DMX_384”** USB disk and open it.
5. In that folder, locate file name **“adj384u.upd”** and delete it.
6. Copy and paste the new version **“adj384u.upd”** file included with these instructions. If you don't have this file, download the zipped file from the **Downloads Tab** on the DMX Operator 384 webpage. <https://www.adj.com/dmx-operator-384>

| | | | | |
|---------------------|----------------|--------|-----------|------|
| Product Description | Specifications | Videos | Downloads | FAQs |
|---------------------|----------------|--------|-----------|------|

Downloads

The following downloads are available for this product:

7. Power OFF the DMX Operator 384 and disconnect the USB cable from the PC.
8. Power ON the DMX Operator 384... the LED display will read **v22**, indicating the software update was successful and complete.