

17 Channels	37 Channels	Values	Functions
1	1	000-255	TILT MOVEMENT (8 BIT)
2	2	000-255	TILT MOVEMENT FINE (16 BIT)
3		000-255	RED ALL 0%-100%
4		000-255	GREEN ALL 0%-100%
5		000-255	BLUE ALL 0%-100%
6		000-255	WHITE ALL 0%-100%
	3	000-255	RED 1 0%-100%
	4	000-255	GREEN 1 0%-100%
	5	000-255	BLUE 1 0%-100%
	6	000-255	WHITE 1 0%-100%
	7	000-255	RED 2 0%-100%
	8	000-255	GREEN 2 0%-100%
	9	000-255	BLUE 2 0%-100%
	10	000-255	WHITE 2 0%-100%
	11	000-255	RED 3 0%-100%
	12	000-255	GREEN 3 0%-100%
	13	000-255	BLUE 3 0%-100%
	14	000-255	WHITE 3 0%-100%
	15	000-255	RED 4 0%-100%
	16	000-255	GREEN 4 0%-100%
	17	000-255	BLUE 4 0%-100%
	18	000-255	WHITE 4 0%-100%
	19	000-255	RED 5 0%-100%
	20	000-255	GREEN 5 0%-100%
	21	000-255	BLUE 5 0%-100%
	22	000-255	WHITE 5 0%-100%
	23	000-255	RED 6 0%-100%
	24	000-255	GREEN 6 0%-100%
	25	000-255	BLUE 6 0%-100%
	26	000-255	WHITE 6 0%-100%
			MACROS
		000-008	No Function
		009-038	Macro 1
		039-068	Macro 2
		069-098	Macro 3
		099-128	Macro 4
		129-158	Macro 5
		159-188	Macro 6
		189-255	Macro 7
7	27		

17 Channels	37 Channels	Values	Functions
8	28		COLOR TEMPERATURES
		000-015	Close
		016-031	2700k
		032-047	3000k
		048-063	3300k
		064-079	3600k
		080-095	3900k
		096-111	4200k
		112-127	4500k
		128-143	4800k
		144-159	5100k
		160-175	5400k
		176-191	5700k
		192-207	6000k
		208-223	6300k
224-239	6600k		
240-255	7000k		
9	29		FOREGROUND COLORS (MOVING COLORS)
		000-007	Red
		008-077	Red-Green
		078-085	Green
		086-155	Green-Blue
		156-163	Blue
		164-233	Blue-Red
		234-241	Red
		242-249	Red-Green-Blue
250-255	Close		
10	30		BACKGROUND COLORS (STATIC COLORS)
		000-007	Red
		008-077	Red-Green
		078-085	Green
		086-155	Green-Blue
		156-163	Blue
		164-233	Blue-Red
		234-241	Red
		242-249	Red-Green-Blue
250-255	Close		
11	31		SHUTTER & STROBE
		000-031	Closed
		032-063	Open
		064-095	Strobing Slow-Fast
		096-127	Open
		128-159	Pulse Effect
		160-191	Open
		192-223	Random Strobing Slow-Fast
224-255	Open		
12	32	000-255	DIMMER 0%-100%
13	33	000-255	DIMMER FINE
14	34	000-255	ZOOM 0%-100%

17 Channels	37 Channels	Values	Functions
15	35		DIMMER MODES
		000-020	Standard
		021-040	Stage
		041-060	TV
		061-080	Architectural
		081-100	Theatre
		101-120	Stage 2
			DIMMER DELAY TIME
		121	0.1Sec.
		122	0.2Sec.
		123	0.3Sec.
		124	0.4Sec.
		125	0.5Sec.
		126	0.6Sec.
		127	0.7Sec.
		128	0.8Sec.
		129	0.9Sec.
		130	1.0Sec.
		131	1.5Sec.
		132	2.0Sec.
		133	3.0Sec.
134	4.0Sec.		
135	5.0Sec.		
136	6.0Sec.		
137	7.0Sec.		
138	8.0Sec.		
139	9.0Sec.		
140	10Sec.		
141-255	Default to Unit Setting		
16	36		TILT SPEED
		000-007	Auto Speed
		008-247	Slow-Fast
		248-255	Auto Speed
17	37		SPECIAL FUNCTIONS
		000-020	No Function
		021-040	Enable Blackout with Tilt Movement
		041-060	Disable Blackout with Tilt Movement
		061-080	Reset All Motors
		081-100	Reset Tilt Motor
		101-120	Reset Zoom Motor
121-255	No Function		