

Checking Battery Status:

This function is used to check the life status of the battery.

Plug the fixture in and press the MODE button until "bXXX" is displayed. "XXX" represents an number between "000" and "100". The number that is displayed is the remaining battery life. If "b---" is displayed, it means the battery is dead or you are running the unit on AC power. *Please do not let the battery fully die, this severly shortens the life of the battery.*

Example: If "b050" is displayed, the battery is at half life. If "b025" is displayed, the battery is at 25% life.

NOTE: When the battery is charging or if the battery life is below 30% the digital display will flicker.

Battery Charging: To charge the battery, plug the supplied AC cord into the AC input on the side of the unit and plug the other end into a matching power supply. After connecting to a power supply, put the Battery switch in the "ON" position. If the display begins to flash, the battery is being charged.

For a faster charging, put the Load Switch into the "**OFF**" position and the Battery Switch into the "**ON**" position.



To charge the battery, connect the unit to AC power, and put the Battery switch into the "ON" position. The display will begin to flash and show the battery life percentage.